

Check for soil settlement at your foundation; fill if necessary to maintain positive slope for water to drain away from the foundation
Inspect eavestroughs and downspouts for loose joints and clear any obstructions
Ensure your sump pump is operating properly in advance before the spring thaw begins (see website for more details)
Ensure the sump discharge pipe is connected and allows water to drain away from foundation
Check for and seal off any holes in exterior cladding
Open valve to outside hose connection after danger of frost has passed
Complete spring landscaping maintenance; fertilize young trees
Inspect the roof and shingles
Check caulking and weather stripping throughout your home
Inspect basement for water issues
Shut down, drain and clean humidifier (if applicable)
Clean filters on your HRV system if necessary
Replace furnace filter if necessary
Check carbon monoxide and smoke detector batteries
Clean windows, screens and hardware and re fit screens that have been removed



